


Pond aerator – Installations for Aqua Farming >

This information bulletin was developed to assist industry, electrical contractors and electricians in applying the correct procedure for the installation of pond aerators.

Procedure

1. Pond Aerators shall be installed as per the diagram below for general arrangement:



Additional protection is required

Any one of the following methods may be used:

- Each motor circuit controlled by residual current device (RCD);
- Isolating Transformers;
- Earth continuity monitoring system (as in mining);
- Extra low voltage supply;
- Insulated sheathed armoured cable.

Note: Single and three phase socket outlets (Power Points) must be RCD protected.

NT WorkSafe >

Electrical Safety
GPO Box 1722
Darwin NT 0801
Website: worksafe.nt.gov.au

Telephone: 1800 019 115
Facsimile: (08) 8999 5141
Email: ntworksafe@nt.gov.au

putting safety first >

