


BULLETIN

Pond aerator – electrical installations for Aqua Farming

This information bulletin was developed to assist industry, electrical contractors and electricians in applying the correct procedure for the installation of pond aerators.

Procedure

Pond Aerators shall be installed as per the diagram below for general arrangement:



Additional protection is required

Any one of the following methods may be used:

- Each motor circuit controlled by residual current device (RCD);
- Isolating Transformers;
- Earth continuity monitoring system (as in mining);
- Extra low voltage supply;
- Insulated sheathed armoured cable.

Note: Single and three phase socket outlets (Power Points) must be RCD protected.

For further information please contact NT WorkSafe on 1800 019 115 or go to worksafe.nt.gov.au